

LAYCOCK SYSTEMS, INC. 1601 North 43rd Street, Tampa, FL 33605 Ph: 813-248-3555 / Fax: 813-242-0514

Email: sales@laycocksystems.com / Web: www.laycocksystems.com

INSTRUCTIONS FOR THE INSULATION FORMER

CROWN MODEL 2301 and 2301M

WARNING: EXCESSIVE CREASING ROLLER PRESSURE WILL DAMAGE POLYURETHANE ROLLER. DO NOT OPERATE WITHOUT INSULATION PAPER IN ROLLERS OR DAMAGE TO THE POLYURETHANE ROLLER WILL RESULT.

Operation:

To Adjust for width of trough:

In setting up for operation, the first adjustment is for desired width of trough. Loosen Allen head setscrews in both creasing rollers and slide on shaft to desired width using graduations on top of scale.

To Adjust Guide Brackets:

To adjust the guide brackets for width of insulation strips, loosen the wing nuts and slide brackets to desired width, using graduations on bottom of scale, then finger tighten wing nuts.

To Adjust for Various Thicknesses of Insulation:

Two thumb screws located at either end of the roller guide supporting shaft, raise or lower this shaft for various thicknesses of insulation. For thicker insulation, these should be turned farther down to provide more pressure between creasing rollers and polyurethane roller. Creasing rollers should always run across the grain of the insulation.

For Model 2301 M. Press the foot switch to activate the motor that operates the Insulation Former. Insulation is guided by two (2) brackets and fed between the creasing rollers and a polyurethane roller for forming.

For Model 2301. Fasten the Insulation Former to the top of bench with wood screws or bolts.

NOTE: Allen Head Wrench for making all adjustments is conveniently located on left side of unit.

Lubrication:

An occasional drop of oil on either end of the creasing roller shaft and polyurethane roller shaft provides for easier operation and longer life.

STORAGE

When not in use, cover unit within a plastic bag.

WARRANTY

Crown's Motor Repair Equipment is warranted to the original owner against defects in materials and workmanship for ninety (90) days from date of purchase. Any part found to be defective (except by overloading, misuse, neglect, fire, accident, tampering with by unauthorized serviceman, or other cause beyond the manufacturer's control), will be replaced or repaired free of charge.

SPECIFICATIONS FOR INSULATION FORMER

Construction:

Iron base & Aluminum hand wheel.

Steel creasing rollers and guides.

Insulation Capacity:

8" maximum width, unlimited length. 6" maximum troughs.

Features:

Easy-to-read scale for fast setups. Adjustable tension for creasing rollers.

Operation:

Insulation is guided by two (2) brackets and fed between the creasing rollers and a polyurethane roller for forming.

Polyurethane roller prevents the creasing rollers from cutting the insulation.

Spare Parts: To be recommended upon request.

Enclosures:

Operating Instructions and equipment repair/replacement parts list.



