


Laycock Quick Release



PART LIST			
ITEM	PART #	DESCRIPTION	QUAN TITY
1	LA-QR-1	QR Block Assembly #1	1
2	LA-QR-2	QR Block #2	1
3	LA-QR-3	QR Block #3	1
4	LA-QR-4	H Block #4	1
5	LA-QR-5	QR Handle Plate	1
6	LA-QR-6	QR Handle	1
7	LA-QR-7	QR Bar	1
8	LA-QR-8	Spacer #1	1
9	LA-QR-9	Spacer #2	1
10	N/A	Head Phillips Machine Screw	3
11	N/A	Hex Nut	1