



PART LIST SW 519			
ITEM	PART#	DESCRIPTION	QUANTITY
1	SW5191	Base	1
2	SW5192	Main Column Assembly	1
3	SW5193	Screws	2
4	SW5194	Support Guide Assembly	1
5	SW5195	Wire Guide 1-5 , 675-660.	1
6	SW5196	Wire Guide 680	1

SW 519
WIRE GUIDE